



# Installation and configuration manual

## With selectronic

**Pytes Lithium Battery E-BOX series**

**With selectronic Inverter**



**CONTENTS**

**BOM LIST** .....3

HOW TO INSATLL ..... 5

**1. Power Cable Connection** ..... 5

    Step.1 ..... 6

    Step.2 ..... 7

    Step.3 ..... 7

**2. Communication Cable Connection** ..... 8

**3. Set The DIP Switch** ..... 9

**4. Start up the system** .....9

**5.Change the battery setting of the inverter** ..... 10

    Step1. .... 10

    Step2. .... 11

    Step 3. .... 12

    Step 4. .... 13

**6.Check the battery data on inverter** ..... 14

    Step.1 ..... 14

    Step.2 ..... 14

## BOM LIST


Before installation, you should prepare following items.

| Item                    | Remarks  | Quantity   |
|-------------------------|--|--|
| <b>Power Cable (DC)</b> | <input type="checkbox"/> Conductor cross-section: 50 mm <sup>2</sup> to 95 mm <sup>2</sup><br><input type="checkbox"/> Cable diameters: 14 mm to 25 mm<br><input type="checkbox"/> Only copper cables may be used.<br><input type="checkbox"/> The DC cables must be sized for the maximum battery voltage and the maximum battery current (see battery manufacturer documentation). | Depends on the number of batteries and the connection method |
| <b>Com. Cable</b>       | CAN communication or RS485 communication   | 1  |
| <b>Battery</b>          | 48100R series /4850  | Depends on the number of batteries and the connection method |
| <b>Inverter</b>         | selectronic  | 1  |


Definition of RJ45 Port Pin for BMS is as follow.

Click [here](#) to tell the version of 48100R you have.

**CAN port definition**

| Version of 48100R      | Pin number of com. cable  |
|------------------------|---|
| <p>B and C version</p> |  <p>1. CAN-H<br/>2. CAN-L<br/>3.<br/>4.<br/>5.<br/>6.<br/>7.<br/>8.</p> |

## HOW TO INSATLL





**CAUTION:** If you want to get more inverter-related settings, please refer to the inverter user manual first.

## 1. Power Cable Connection


### Step.1

Open the front housing of the selectronic inverter.



## Step.2

Connect the red and black cables to the inverter DC connector as shown in Pic .1.1.1



Pic 1.1.1

## Step.3


At the other end of the cable, connect to the battery as shown Pic 1.1.2. (Ensure that the battery power switch is off)



Pic 1.1.2

## 2. Communication Cable Connection


Connect the end of the cable to the inverter communication port as shown in pic 1.2.1. Make sure which communication port to use.



Pic 1.2.1

Connect the other end of the cable to the battery communication port as shown in pic 1.2.1. (Ensure the correct sequence of communication cable)





Pic 1.2.2

### 3. Set The DIP Switch


Set the DIP switch as shown in Pic 1.2.3.

| Version of 48100R | ADD setting |
|-------------------|-------------|
| A and B version   |             |
| C version         |             |

Pic 1.2.3

### 4. Start up the system

Restore the cover plate of the inverter, Start up the inverters and batteries.



## 5.Change the battery setting of the inverter

※ **CAUTION:** If you want more details about the batteries settings , please check the operating manual of inverters.

### Step1.

Connect the host computer cable from the inverter to the laptop.




Pic 1.5.1




Pic 1.5.2

## Step2.

Go to selectronic <https://www.selectronic.com.au/splink/> and download the SP LINK.




Pic 1.5.3




Pic 1.5.3

### Step 3.

Connect and select the protocol.




Pic 1.5.4



Pic 1.5.5

## Step 4.

Set the parameters of the battery on the inverter. Please check the battery E-BOX 48100R user manual for detailed parameters



## 6. Check the battery data on inverter

### Step.1


Touch the Quick View can see the battery data.



Pic 1.6.1

### Step.2

Click the **Data View** can see detail datas.



Pic 1.6.2

-END-